OUTDOOR ESSENTIALS LIGHTING LITO LED

# LITO LED LAMP

The mobile LITO lamp creates new standards. Enjoy the magical mood lighting of our popular LITO lanterns now also outdoors. The classic design details are complemented by an LED head that illuminates your garden in three different spectral colours, depending on your preference. The lamp is rechargeable and will light up some cosy barbecue evenings with friends, as it has a long operation time. Simply touch the button on the top, choose your desired spectral colour, dim up to your desired light intensity and get enchanted by the wonderful lightness of LITO LED. The outdoor LED is rechargeable via USB-C and can be adjusted between the three light colours warm white, mix and cool white. The bulb is not replaceable, but thanks to the LED has an extremely long life of over 20,000 hours.



LITO LED 67477

Mobile LED Lamp White H 12 cm. Ø 13.5 cm



LITO LED 67476

Mobile LED Lamp Black H 12 cm, Ø 13.5 cm



LITO LED 67478

Mobile LED Lamp Mourning Dove H 12 cm. Ø 13.5 cm



LITO LED 67480

Mobile LED Lamp Ocean Cavern H 12 cm, Ø 13.5 cm



LITO LED 67481

Mobile LED Lamp Agave Green H 12 cm, Ø 13.5 cm

Mobile LED Lamp

H 12 cm, Ø 13.5 cm

Nomad



LITO LED 67052

Mobile LED Lamp Silk Gray H 30,5 cm, Ø 27,5 cm



LITO LED 67055

Mobile LED Lamp Silk Gray



H 49 cm, Ø 31 cm



### LITO LED 67053

Mobile LED Lamp Granite Gray H 30,5 cm, Ø 27,5 cm



#### LITO LED 67056

Mobile LED Lamp Granite Gray H 49 cm, Ø 31 cm



## LITO LED 67054

Mobile LED Lamp Black H 30,5 cm, Ø 27,5 cm



# LITO LED 67057

Mobile LED Lamp Black H 49 cm, Ø 31 cm



## Care and use

- Weather conditions, as well as the way the lanterns are used, will have an influence on the product. To enjoy it for a long time, we recommend to cover them in the winter, or store it in a dry, sheltered area.
- Protect the lanterns from extreme weather conditions such as heavy rain, wind or storms to prevent long-term damage caused by moisture or corrosion. Please wipe the lanterns if they get wet after rain or snowfall.
- Please remove stains and soiling immediately to prevent permanent damage to the lanterns.
- If the lanterns are used near the sea, please wipe them regularly with warm water to prevent salt deposits. Please note that proximity to the sea can shorten the service life of the
- Avoid contact with sharp or scratching objects. Please protect the lanterns from scratches.
- Avoid contact with aggressive, corrosive or abrasive chemi-
- Please check the condition of the silicone feet on the underside of the lanterns regularly and reattach them if they fall off.



